

Adjustments for *AutoTension*[™] Control

For maximum seating comfort we recommend that you adjust your chair in the numerical steps indicated below.

