



## Cleaning & Disinfecting Instructions for Sitmatic Chairs

Sitmatic recommends regular vacuuming or light brushing to prevent dust and soil buildup. Use a vacuum with a HEPA filter for fabrics before disinfecting. Dispose of the filter after vacuuming.

### Cleaning & Disinfecting

Cleaning refers to the removal of germs, dirt, and impurities from surfaces. It does not kill germs, but by removing them, it lowers their numbers and the risk of spreading infection. Do not saturate or soak fabric with cleaner or disinfectant.

After cleaning your chair, disinfecting kills germs and viruses and can further lower the risk of spreading infection.

Rinse with clean water after procedure to eliminate residue. This will prolong the life of various components (thread, seams, foam, etc.) than can be impacted by cleaner & disinfectant residue. Do not saturate or soak fabric with cleaner or disinfectant.

		Regular Cleaning	Disinfecting
Polyurethane & Vinyl	Durathane™ Polyurethane	1:10 Soap / Warm Water Solution	1:50 Bleach / Water Solution (CDC approved to use against SARS-CoV-2), Isopropyl Alcohol (70%), Formula 409®, Clorox® Disinfecting Wipes, Lysol® Disinfecting Wipes, Lysol® Disinfectant Spray.
	Durahyde™ Vinyl		
	Ecohyde™ TPE		
	Vigil™ Polyurethane		
	Echelon™ Polyurethane		
	Aerohyde™ Polyurethane		
Leather	Pieno Fiore™ Leather	1:10 Soap / Warm Water Solution	1:48 Bleach / Water Solution
Fabric & Mesh	All Other Sitmatic Carded Fabrics including Mesh	1:10 Soap / Warm Water Solution	1:50 Bleach / Water Solution (CDC approved to use against SARS-CoV-2), Lysol® Disinfectant Spray (Spray until the chair is covered in mist, allow to air dry for 10 min.)
	Chair Frames, Plastic Parts & Hard Components	1:10 Soap / Warm Water Solution	Same as Polyurethane & Vinyl
<b>**Always rinse with fresh water and allow the chair to thoroughly dry before use, as moisture will cause more dirt to cling to the chair's surface.**</b>			

### Prepare a (CDC Approved) 1:50 bleach solution by mixing:

- 5 tablespoons (⅓ cup) bleach per gallon of water or
- 4 teaspoons bleach per quart (32 oz.) of water.



View instructional video using this QR code or by visiting [www.sitmatic.com/clean](http://www.sitmatic.com/clean) in your browser.

Wear disposable gloves when cleaning and disinfecting surfaces. Gloves should be discarded after each cleaning. If reusable gloves are used, those gloves should be dedicated for cleaning and disinfection of surfaces for COVID-19 and should not be used for other purposes. Consult the manufacturer's instructions for cleaning and disinfection products used. Clean hands immediately after gloves are removed.

Warning: this information is not a guarantee. Please use all cleaning and disinfecting agents safely and as instructed. The use of other cleaning agents, disinfectants, conditioners, or protectants can degrade fabric performance and may void Sitmatic warranty.





**SITMATIC®**



## Bleach Cleanable Leather Care & Maintenance or Sanitizing & Disinfecting

Sitmatic recommends regular vacuuming or light brushing to prevent dust and soil buildup.

**Pieno Fiore™ Leather is approved for 1:48 ratio (1 part bleach to 48 parts water).**

### Bleach Cleanability

BIFMA Health Care Furniture 8.1-2017 Section 7: Household bleach (sodium hypochlorite). CDC/EPA recommended ratios (1:10 or 1:48) parts bleach to water for the sanitizing and disinfecting of viruses and bacteria. Reference CDC/EPA and product specifications for approved dilution ratio and cleaning agent instructions for dwell time.

### Cleaning Instructions

1. Use CDC/EPA recommended solution per leather product specifications. Gently apply (wipe) using a soft clean cloth (do not aggressively scrub). Do not saturate.
2. Allow solution to remain on surface according to recommended cleaning agent label dwell time.
3. Gently wipe off cleaning mixture residue using a clean damp cloth to prevent fading and long term damage to the leather. It is important to remove cleaning agent residue as it may continue to degrade surfaces and shorten the life and/or affect the appearance of the surface material.

### Long Term Maintenance

Monthly: Apply leather protector to restore the leather's protective barrier.

Quarterly: Apply leather softener to re-nourish the leather's moisture and softness.

Recommended cleaning products are available through Leather Solutions Intl at [www.leathersi.com](http://www.leathersi.com).

**DO NOT USE ANY CLEANING PRODUCTS CONTAINING ALCOHOL.**

### References

CDC Guidelines for Disinfection and Sterilization in Healthcare Facilities (recommended ratio 1:10)

<https://www.cdc.gov/infectioncontrol/guidelines/disinfection/index.html>

CDC Reopening Guidance for cleaning and disinfecting Public Spaces, Workplaces, Businesses, Schools and Homes (recommended ratio 1:48).

<https://www.cdc.gov/coronavirus/2019-ncov/community/reopen-guidance.html>

CDC Cleaning and Disinfecting Your Facility (recommended ratio 1:48).

<https://www.cdc.gov/coronavirus/2019-ncov/community/disinfecting-building-facility.html>

